
## breezesta™

## DOUBLE COASTAL GLIDER AD-0114






PARTS				
PART	DESCRIPTION	PART NO.	QTY	
А	FRONT LEG ASSEMBLY	SA-00101	2	
В	UNDER ARM SUPPORT	PRT-00146	2	
С	LEFT BACK LEG ASSEMBLY	SA-00102	1	
D	RIGHT BACK LEG ASSEMBLY	SA-00103	1	
E	LEFT ARM ASSEMBLY	SA-00458	1	
F	RIGHT ARM ASSEMBLY	SA-00459	1	
G	SEAT ASSEMBLY	SA-00094	1	
Н	DOUBLE COASTAL GLIDER SPREADER	SS-34.5	3	
I	STOP BAR	PRT-00197	1	
J	BASE SIDE RAIL	PRT-00422	2	
K	LEFT BASE FOOT ASSEMBLY	SA-00420	2	
L	RIGHT BASE FOOT ASSEMBLY	SA-00419	2	
М	SEAT SUPPORT	PRT-00184	1	
N	CENTER BACK ASSEMBLY	SA-00097	1	
0	LEFT BACK ASSEMBLY	SA-00095	1	
Р	RIGHT BACK ASSEMBLY	SA-00096	1	
















HARDWARE				
PART	DESCRIPTION	PART NO.	QTY	
а	#8 X 1-1/2" TORX SCREW	H-0000-S815	2	
b1	#8 X 2" TORX SCREW-FRAME COLOR	H-0000-S82	18	
b2	#8 X 2" TORX SCREW-UNPAINTED	H-0000-S82	5	
С	#8 X 2-1/2" TORX SCREW	H-0000-S825	4	
d	5/16" X 1-1/2" CHAIR BOLT	H-0000-CB51615	10	
е	5/16" X 2-1/8" CHAIR BOLT	H-0000-CB516218	14	
f	DOUBLE SCREW	H-0000-DS	4	
g	T20 & T25 TORX BIT	H-0000-CTD	1	


Suggested Tools: Drill, Plastic Mallet


## Please read entire instructions before beginning





**1.** Starting with Part C, attach Parts C & A to Part E by inserting Hardware f into the predrilled holes and rotating clockwise, stopping when the assembly is tight

- **2.** Place Part B into the pre-cut slot and attach with Hardware c
- **3.** Repeat Steps 1 & 2 with Parts A, B, F, D










**8.** Connect Parts H to Parts J using Hardware b



**9.** Attach Part I to the previous assembly

