
## breezesta™


## **48" ROUND DINING TABLE**

DH-0704





PARTS				
PART	DESCRIPTION	PART NO.	QTY	
Α	SIDE ASSEMBLY	SA-00318	2	
В	SPREADER	PRT-00634	4	
C	BASE SPREADER	PRT-00635	1	
D	TABLE TOP ASSEMBLY 48"ROUND	SA-00319	1	



HARDWARE				
PART	DESCRIPTION	PART NO.	QTY	
а	#8 X 1-1/2" TORX SCREW	H-0000-S815	4	
b	1/4-10 x 3" LAG	H-0000-S103	20	
С	#8 x 3/4" TORX SCREW	H-0000-S834	4	
d	L BRACKET FOR TABLE TOPS	H-0000-MLB	4	
е	T20 & T25 TORX BIT	H-0000-CTD	1	

Suggested Tools: Drill, Plastic Mallet

## Please read entire instructions before beginning

**1.** Attach Part B and Part C to Part A using Hardware b, attach Hardware d to Part A using Hardware a

